



ATV/Golf Cart Rack

1. The Overbilt customized 3 tube receiver must be welded onto coach before assembling the rack system.

2. Insert the right and left extensions into the two outside tubes of the camper receiver.



3. Next, attach the towbar receiver onto end of extensions. The holes for the towbar receiver are predrilled for easy installation. Use four 1 1/4" bolts to attach the sides of the towbar to the extensions.



Overbilt Lifts says:

“Don’t live in a garage, keep that behind your coach because

He Who Takes the MOST Toys With Him, Wins!!”



4. Attach the tray closest to the motorhome with four 1 1/4" bolts. Holes are predrilled for easy installation.



5 Attach the tray farthest from the coach with 3 1/2" bolts. This tray will sit right on top of the towbar receiver. The 3 1/2" bolts go through the tray and into the top holes of the towbar receiver. Securing both the tray and towbar with the same bolts.



6. Tail lights should be wired to pre-existing plug on coach. Attach the taillights to the tray furthest from the coach in the pre drilled holes. Then load "toy" to be carried, secure the cargo, and enjoy your new Overbilt ATV/Golf Cart Rack!!

Helpful Hint:

The loading ramps can be stored in between the two trays after the "toy" is safely on the rack.

Overbilt says, Don't live in a garage, keep that behind your coach because
"He Who Takes The MOST Toys With Him, Wins!!!"