

BOLTING AND WELDING END PLATES TO FRAME

Place end plates on frame with vise grips, mark bolt pattern if necessary.

Center camper receiver in end plates,

If frame rails are short, extend them first using a minimum of 1/4 inch tubing or 3/8 inch plate steel.

Once end plates are installed and receiver is in place, make sure it is level, tack weld in place and double check to be sure it is plum and level.

Now weld completely around receiver tube and end plates on both sides.

ANY QUESTIONS? CALL 845-382-1369 ASK FOR ART.

Measurements for the engine compartment to open
Place the lift assembly in your original receiver and open and close hood. Now measure for future reference when installing new receiver. Max height 20" to bottom of receiver.

