



Troubleshooter for Electric Winches

1. Make sure when installing winch, the switch is on the top.
2. Make sure cable is grounded out properly.
3. Make sure cable is wired directly to the battery.
4. Keep cable and pulleys properly lubed.
5. Make sure battery is fully charged
6. Make sure cable is not kinked.
7. Make sure cable is neatly and evenly spooled
8. Make sure terminals on the switch are corrosion free

Helpful Hint:

**If winch not working, stick long handled screwdriver in the bottom opening of winch and turn slightly. This will work any corrosion on the spool loose, but don't hold screwdriver tight, this will turn as well when corrosion breaks free.

If unable to find or fix problem, please call Art or Shawn immediately
In US toll free 866-382-1369
International/fax- 845-382-1369

